



Sundi WPC Maintenance

WPC deck can be cleaned with a brush /sanding paper, or with a high pressure cleaner. If you clean the terrace with a high pressure cleaner, you must keep a distance of at least 30cm from the terrace sections. If necessary you can use a neutral soap. Make sure that the detergent doesn't attack plastic. Following is some recommendations in details;

1. Water stains

There will be some water stains on the surface of the newly installed terrace when the water evaporates after rain. It is temporary phenomenon which will disappear in about 1-2 months by itself. It can be cleaned by wiping the surface with steel wool.

2. Mud, dust, etc.

Clean decking to remove dirt by using hot water with soap. Sand it with stiff bristle if needed.

3. Scratch, oil stains, alcohol stains, and cigarette stains etc. which are hard to be removed from the surface. Use steel wool or sandpaper carefully to try to remove the stain. Then sand surface and clean with hot water with soap.

Claims:

The claims are exclusively and unconditionally only for production faults of the material Claims cannot be made for material on which product faults are visible that has already been used, machined and / or processed. Claims never apply to unauthorized use or incorrect application of the material. Seller will offer the new material to replace the bad products only, and not be liable for cost related such as installation costs, transportation and delivery costs, or time and labor. All typesetting and printing errors reserved.